7) INSTALL THE DART PLACARD ONTO THE TOP OF THE CASE IN AVAILABLE AREA USING ALUMINIUM POP RIVETS

6

5

8) HOT GLUE THE CONTENT PLACARD ONTO THE TOP FOAM

7

9) HOT GLUE THE TOP AND BOTTOM FOAM INTO THE CASE

WINDOWS INSTALLATION TOOL KIT

2

COPYRIGHT © 2019 BY DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

DATE 2019-05-31

3

NTS

D







